

MINI MASSAGER

Ergonomiskt utformad Intim-massager med 11 vibrationslägen och uppladdningsbart batteri. Mini Massager är tillverkad i mjuk silikon.

INSTRUKTIONER

1. LADDNING: För varsamt in laddningskabeln i Mini Massager. Koppla in andra änden (USB) i en strömadapter för USB-laddare eller en USB-port på datorn. En röd lampa tänds medan Mini Massager laddas och släcks sedan när den är fulladdad.

LADDNINGSTID: 120 minuter
KÖRTID: 60 minuter

2. LÅS UPP OCH AKTIVERA: Håll ner båda knapparna några sekunder för att låsa upp Mini Massager. Tryck på den övre knappen för att bläddra upp bland de 11 olika vibrationslägena och den nedre för att gå tillbaka.

3. LÅS OCH DEAKTIVERA: Bläddra dig ner genom vibrationslägena tills Mini Massager är avstängd. Håll ner båda knapparna några sekunder för att låsa produkten.

OBS: Om båda knapparna trycks ner under ett vibrationsläge så låser sig det läget, håll sedan ner de två knapparna igen i några sekunder för att låsa upp.

4. UNDERHÅLL: Tvätta noggrant före och efter varje användning med ett desinficerande rengöringsmedel för intim-produkter. Använd endast vattenbaserat glidmedel. Undvik att sänka Mini Massager helt i vatten och undvik att få vatten i laddnings-hålet.

PRODUKTSPECIFIKATION:

- Silikon/ ABS
- 1 tyst motor
- 11 vibrationslägen
- Längd: 8 cm
- Ø: 3.8 cm
- Uppladdningsbart integrerat batteri
- Vattentålig: Stänksäker
- Ftalatfri

MINI MASSAGER

Intimate massager made with super soft silicone. Ergonomic massager with 11 vibration modes and rechargeable battery.

INSTRUCTIONS

1. CHARGE: Insert the charger into the charging socket. Plug into the wall socket or to your computer port through the USB end. A red light will turn on while the product is charging. When it is fully charged, the light will turn off.

FULL CHARGE TIME: 120 min.
APPROXIMATE USE TIME: 60 min.

2. UNLOCK AND ACTIVATION: Press for a few seconds both buttons simultaneously to unlock the product. Press successively the superior button to move up through the 11 different modes.

3. LOCK AND DEACTIVATION: Move down through the different modes with the inferior button until it is turned off. Then press both buttons simultaneously to lock it.

Attention: If both buttons are pressed simultaneously during a vibration mode, the mode will remain locked. Press both buttons again for a few seconds to unlock it.

4. MAINTENANCE: Wash carefully with neutral soap and water before and after every use. Do not use silicone-based lubricant.
* It is advisable not to make excessive use under water. Avoid sinking or getting the connections wet.

TECHNICAL FIXTURES:

- ABS with Silicone finish
- 1 ultra-silent motors
- 11 vibration modes
- Length: 8 cm
- Ø: 3.8 cm
- Rechargeable battery.
- Splash proof.
- Phthalate free.



Representante autorizado:

CNEX AIE,SL
C/Mendez Nuñez,49
08032 Mataró
BARCELONA-SPAIN
Tel:+ 34 933 806 526
Fax: +34 933 806 528

Distribuerad av:

Jewa Sweden AB
www.jewasweden.se

www.femintimate.se



FEMINTIMATE
Mini Massager

