



chorus™

Get ready for your next adventure

We-Vibe® Chorus™ is the most intuitive couples vibrator ever. All the features you know and love from We-Vibe are here, and Chorus has new technology that was developed based on years of customer feedback. With an adjustable fit, touch-responsive controls and hands-free vibrations, Chorus takes sex to a whole new level.

Chorus provides endless pleasure for couples to explore. The Squeeze Remote and Touch-sense modes let you control the vibes intuitively, so every time is different (if you want it to be).



SQUEEZE REMOTE

Try Squeeze control with the new Squeeze Remote. It was designed with the most natural human response in mind — the tighter you squeeze, the stronger the vibration gets. Release your grip and the vibration weakens. This technology lets you change things up in the heat of the moment. Explore seamless pleasure, together.

You can still change vibration patterns and base vibration intensity while in Squeeze control — just use the Squeeze Remote as you would any other We-Vibe remote.



ANKORLINK™

Chorus is the first We-Vibe powered with AnkorLink technology — it creates the most stable connection between Chorus and the We-Connect™ app. The Squeeze Remote is the anchor between Chorus and We-Connect. You can't pair Chorus to We-Connect without the Squeeze Remote, so make sure you keep it close by while using the app.


Bluetooth signals are reflected by water. Since over 80% of our body consists of water, Bluetooth's reliability is limited. AnkorLink solves this problem by enhancing Bluetooth connections.



TOUCH-SENSE

Using touch-sensitive receptors located underneath the We-Vibe logo, Touch-sense lets you control Chorus' vibrations with your movements. When you touch or move against the sensor, the vibration changes. Choose your own adventure with three Touch-sense modes.

Unlock Touch-sense with We-Connect.



MODE 1

With each touch to the sensors, the vibrations step up in intensity until Chorus reaches max power, then the vibrations step back down to the lowest setting before repeating this pattern.

Try this mode to build a rhythm with your partner.



MODE 2

Chorus will vibrate in a slow wave pattern. When contact is made with the sensors, the vibrations will hold at that intensity. When contact stops (for 3 seconds or longer), the vibrations will return to the wave pattern.

Find your favourite intensity together and hold on to it with a close grip.



MODE 3

Vibrations will turn on when contact is made with the sensors, and turn off once contact stops. This mode works the same way Smart Silence does in other We-Vibe products.

Edge and tease your partner to pleasure by turning the vibes on and off.





Turn on and get turned on

Did you know? Couples who listen to music aloud together report having 67% more sex than those that don't.*

* Music Makes It Home study by Sonos, 2016

Playlist: Find Your Vibe

1. Open Spotify
2. Tap Q
3. Scan



HOW TO USE CHORUS™

Pair to Squeeze Remote:

1. Press and hold the control button on Chorus for 10 seconds (Chorus will pulse twice — continue holding the button until the light flashes 3 times).
2. Press and hold the "+" button on the remote until Chorus pairs to the remote (Chorus will pulse 3 times once paired).
3. Press any button on the remote except for the function button (top button with wave) to feel Chorus respond. If Chorus responds, the remote is successfully paired to Chorus.

Activate Squeeze Control:

1. To activate Squeeze control on the Squeeze Remote, press and release the function button. The light on the remote will flash 3 times.
2. Squeeze and release the remote to feel changes in the strength of the vibrations. Repeat as desired.
3. To stop using Squeeze control, press and release the function button. The light on the remote will flash 2 times.


Pair to We-Connect:

1. Press and hold the control button on Chorus for 5 seconds (until it pulses twice).
2. You can then begin the pairing process within the We-Connect app.

Note: You cannot pair Chorus to the We-Connect app without the Squeeze Remote. Chorus uses AnkorLink technology to create a stable connection between Chorus and the app, and the Squeeze Remote is the anchor between this connection. Make sure you keep the Squeeze Remote close by whenever you use We-Connect.

ADJUSTABILITY

Chorus' shape is customizable. Make small adjustments to the position of either the clitoral or G-spot stimulator to find the fit that's right for you.



FEATURES

- Squeeze Remote
- Touch-sense modes
- AnkorLink™ technology
- We-Connect™ app compatible
- Adjustable fit
- Waterproof
- Whisper quiet
- Low power alert
- Storage/charging case included
- USB cord with magnetic charging pins
- Run time: 90 minutes
- Charge time: 120 minutes
- Body-safe silicone
- 10+ modes

VIBRATION MODES



MSRP

\$199 USD / \$229 CAD / \$299 AUD / 199€ / £179

COLORS



DIMENSIONS

