

DUAL MASSAGER

Dual Massager är en dubbel U-formad vibrator med flera vibrationslägen. Utformad för att stimulera både utvändigt och invändigt samtidigt men designen på Dual Massager möjliggör två olika tillvägagångssätt för njutning. Dual Massager är tillverkad i mjuk silikon och är väldigt flexibel och rörlig för en mer behaglig och enkel användning.

INSTRUKTIONER

1. LADDNING: För varsamt in laddningskabeln i Dual Massager. Koppla in andra änden (USB) i en strömadapter för USB-laddare eller en USB-port på datorn. En röd lampa tänds medan Dual Massager laddas och släcks sedan när den är fulladdad.

LADDNINGSTID: 120 minuter

KÖRTID: 130 minuter

2. PÅ-/AVSTÄNGNING SAMT VIBRATIONSMENY: För att sätta på vibrationerna håll in knappen några sekunder. Tryck sedan på knappen för att bläddra mellan de olika vibrationslägena. Håll sedan inne knappen några sekunder för att stänga av vibrationerna.

- (Illustration A) För in båda ändarna: På detta användningssätt blir Dual Massager en kraftfull vibrator med G-punktsstimulans.
- (Illustration B) För in den långa änden och låt den andra änden vila på klitoris: På detta användningssätt får du dubbel stimulans på både G-punkten och klitoris samtidigt.

3. UNDERHÅLL: Tvätta noggrant före och efter varje användning med ett desinficerande rengöringsmedel för intim-produkter. Använd endast vattenbaserat glidmedel. Undvik att sänka Dual Massager helt i vatten och undvik att få vatten i laddnings-hålet.

PRODUKTSPECIFIKATION:

- Silikon/ ABS
- 2 tysta motorer
- 10 vibrationslägen
- Längd: 18 cm
- Ø: 3.2 cm
- Uppladdningsbart integrerat batteri
- Vattentålighet: Stänksäker
- Ftalatfri

DUAL MASSAGER

Double intimate U shaped massager with multiple vibration modes. Intended for an external and internal simultaneous massage, its shape offers a 2 different ways of use.

Dual Massager is made with extra soft silicone and a great flexibility and mobility for a more comfortable and easy use.

HOW TO USE

1. CHARGE: Introduce gently the DC jack of the USB cable into the DC socket situated below the A button. Connect it to a wall plug or to the USB port of a computer. A light up whilst charging and goes off once the device is fully charged.

FULL CHARGE TIME: 120 min.

APPROXIMATE USE TIME: 130 min.

2. ON AND GO THROUGH THE VIBRATION MENU: to turn on the G-Wave press a few seconds on the "A" button, to move through the modes and change the vibration intensity

- (Illustration A) Inserting both ends: Dual massager turns into a powerful vibrator with G-spot stimulation.
- (Illustration B) Separating both ends from each other: for an independent and simultaneous G-Spot and clitoral stimulation.


3. OFF: to turn off the Dual Massager press a few seconds on the "A" button.

4. MAINTENANCE: Wash it carefully with water and neutral soap before and after each time you use it. Use only with water based lubricant. Avoid submerging and getting water into the USB plug.


TECHNICAL FIXTURES:

- Silicone / ABS
- 2 quiet motors
- 10 vibration modes
- Length: 18 cm
- Ø: 3.2 cm
- Rechargeable battery
- Splash proof
- Phthalates free

A



B



Representante autorizado:

CNEX AIE,SL
C/Mendez Nuñez,49
08032 Mataró
BARCELONA-SPAIN
Tel: + 34 933 806 526
Fax: +34 933 806 528

Distribuerad av:

Jewa Sweden AB
www.jewasweden.se

www.femintimate.se



FEMINTIMATE

Dual Massager

