

womanizer

— THE ORIGINAL —

CLASSIC

BEDIENUNGSANLEITUNG / MANUAL / MODE D'EMPLOI / MANUAL DE INSTRUCCIONES /
ISTRUZIONI PER L'USO / ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ / 사용 설명서 / 操作説明書




Hi!

Schön, dass Du Dich für Womanizer entschieden hast.

Wir heißen Dich willkommen in einer Welt voll sinnlicher Erlebnisse, die Dich und Dein Leben immer wieder aufs Neue bereichern. Mit der Entscheidung für den Womanizer sind Dir nicht nur unvergleichliche Orgasmen sicher – sondern auch ein vollkommen neues Lustgefühl. Feiere Deine Weiblichkeit und genieße Dich. Lass Dir nichts entgehen! Keinen Orgasmus, keine Fantasie, kein Vergnügen. Hab viel Freude mit dem Produkt – und einen Orgasmus nach dem anderen.

Thank you for choosing Womanizer.

Welcome to a world full of sensual experiences that will enrich you and your life time and again. By choosing the Womanizer, you are not only guaranteed orgasms that are beyond comparison, but also an entirely new lust for pleasure. Celebrate your femininity and enjoy yourself. Don't miss out! Not on any orgasm, fantasy, or pleasure. Enjoy your product – and one orgasm after the next.



Pleasure-Air-Technologie
Pleasure Air Technology



8 Intensitätsstufen
8 intensity levels



Wasserdicht
Waterproof



Body Fit



**2 Stimulations-
aufsätze aus Silikon**
**2 silicone
stimulation attachments**



Lautlose Technologie
Silent Technology





BESCHREIBUNG

LADEN

KURZANLEITUNG

BENUTZUNG

TIPP

REINIGUNG

ALLGEMEINE INFORMATIONEN

HINWEIS: Bitte lies diese Bedienungsanleitung vor dem ersten Vergnügen mit Deinem Womanizer aufmerksam durch und bewahre sie für eine spätere Verwendung gut auf.

DESCRIPTION

CHARGING

QUICK GUIDE

USE

TIPS

CLEANING

GENERAL INFORMATION

NOTE: Please read these instructions carefully before your first pleasurable experience with your Womanizer and store them safely for later reference.

BESCHREIBUNG

- A** MAGNETPINS ZUM LADEN
 MAGNETIC CHARGING PINS

- B** AN/AUS-KNOPF
 ON/OFF BUTTON




- C+** INTENSITÄTSKNOPF KLITORISSTIMULATION (ERHÖHEN)
 INTENSITY BUTTON FOR CLITORAL STIMULATION (INCREASE)


- C-** INTENSITÄTSKNOPF KLITORISSTIMULATION (SENKEN)
 INTENSITY BUTTON FOR CLITORAL STIMULATION (DECREASE)

DESCRIPTION

- D** STIMULATIONSAUFSATZ
 STIMULATION ATTACHMENT

- E** USB-LADEKABEL MIT LADEKOPF
 USB CHARGING CABLE WITH CHARGING HEAD





CHARGING

WARNING:

To make sure you get real pleasure from your Womanizer from the start, you should note a few things:

Before using the charging device for the first time, check the local voltage level, since the local mains voltage may not exceed the maximum mains voltage given on the device.

Never immerse the charging device or charging cable in water or other fluids.

Do not rinse the charging device and charging cable in running water.

Check the stimulation device regularly for any damage.

Do not use the device if one of the components is damaged.

PLEASE NOTE:

When you first hold the Womanizer in your hands, the rechargeable battery is only pre-charged for a short period of use. Since the rechargeable battery may have discharged fully due to environmental influences, we recommend that you fully charge the Womanizer before your first use. The charging process takes about two hours. If your Womanizer becomes warm during the charging process, this is entirely normal. After charging, you can experience up to 240 minutes of sensual pleasure with your Womanizer. The duration of the actual operating time depends on how intensively you enjoy your time with the Womanizer.

CHARGING

CHARGING STATUS DISPLAY

Your Womanizer has an LED around the on/off button (B). It functions as a charge status display during charging.

PLEASE TAKE THE FOLLOWING STEPS IF YOU WISH TO CHARGE THE RECHARGEABLE BATTERY IN YOUR WOMANIZER:

1. If you switch your Womanizer on and the ON/OFF button (B) flashes, charge it.
2. Make sure that your Womanizer and the charging device are dry.
3. Connect the USB charging cable (E) to a suitable USB connection (such as an adapter or PC, or similar).
4. Place the charging head (E) on the magnetic pins (A).
5. Despite the magnetic attraction of the pins, make sure that the charging head (E) is optimally positioned on the device and your Womanizer is in a secure position for charging).
6. During charging, the on/off button (B) flashes.
7. Your Womanizer is charged when the on/off button (B) stays lit.

KURZANLEITUNG • QUICK GUIDE

1. ON/OFF

Zwei Sekunden gedrückt halten.
Keep pressed down for two seconds.

Empfohlene Haltung.
Recommended position.






2.



3.



4.

USE

NOTE:

Before using your Womanizer, please remove any piercings or jewelry in your intimate zone.

MANUALLY INCREASING AND DECREASING INTENSITY LEVELS:

1. Keep the button (B) pressed down for two seconds to switch on your Womanizer.
2. Lightly splay apart your labia with your fingers to expose your clitoris.
3. Now you can place the stimulation head (D) tightly onto your clitoris, applying slight pressure, so that it is held in the oval opening of the stimulation head.
4. As soon as the stimulation head is perfectly positioned on your clitoris, you can start – and the moment is yours alone. Experience it as you like it: If you desire more intensity, then briefly press the button (C+) and the intensity increases by one level. You can repeat this step seven times, then the highest level of intensity has been reached. On every change of level, the LED lights up once. If you have already reached the highest level, the LED remains unchanged.
5. In order to reduce the intensity, briefly press the button (C–). The intensity is decreased by one level for each click. When decreasing intensity, the LED also lights up once for every change in level.
6. To hold your Womanizer in the desired position, you can close your thighs. Naturally, you can also simply hold the device in your hand.

7. Once your personal Womanizer moment has passed, simply switch off the device by pressing the button (B) for approx. two seconds.

IMPORTANT INFORMATION:

Please do not use perfumed or alcohol-based lube gels or massage oils while using the Womanizer in order to avoid damage. Silicone-based lube gels are not recommended. If required, it's better to use a water-based lube gel with the Womanizer.

A SMALL TIP:

If you notice that the stimulation attachment doesn't yet have the optimal fit, switch between the two stimulation attachments (S and M) included with the device to create the best feeling for you.

TIPP

ENTDECKE NEUE, AUFREGENDE SEITEN AN DEINEM WOMANIZER!

STANDBY-FUNKTION:

Die Standby-Funktion gestaltet für Dich die Handhabung Deines Womanizer besonders akkufreundlich und komfortabel: Bei Nichtverwendung schaltet sich das Gerät innerhalb von 30 Minuten selbst ab.


TIPS

DISCOVER NEW, EXCITING SIDES TO YOUR WOMANIZER!

STANDBY FUNCTION:

The standby function makes handling your Womanizer convenient for you and ensures better battery usage: when not in use, the device switches itself off after 30 minutes.

REINIGUNG • CLEANING



CLEANING

HERE'S HOW TO CLEAN YOUR WOMANIZER:

Your Womanizer is 100% watertight and is easy to clean. For ideal cleaning, we recommend that you use a sex toy cleaner.

PLEASE NOTE:

When changing the stimulation attachments or cleaning the Womanizer head, we recommend that you switch off the Womanizer.

CLEANING YOUR WOMANIZER IN TEN EASY STEPS:

1. Make sure that the charging cable has been disconnected.
2. Remove the stimulation attachment from the device.
3. Clean the stimulation attachment in hot water and treat it with a sex toy cleaner.
4. Then put the sex toy cleaner into the pressure chamber and let it briefly take effect.
5. Switch the Womanizer to the highest level and immerse it into warm water for one minute.
6. You can then shake out your Womanizer.
7. Keep your Womanizer switched on until the noises caused by contact with the water can no longer be heard.
8. Now switch off the Womanizer and dry it off with a cloth.
9. You can also clean the compression chamber with a cotton wool bud and sex toy cleaner.
10. Finally, reapply the stimulation attachment and you're done.

GENERAL INFORMATION

USE

Thoroughly clean your Womanizer before using it for the first time, after each usage, and when using in another body area in order to reduce the risk of infection (see section "How to clean your Womanizer").

STORAGE

Place the cleaned Womanizer back in the storage box. Store in a secure, dry place without exposure to direct sunlight.

TECHNICAL DATA

Model: Classic
Charging device: Input: 100–240 V ~ 50/60 Hz
Output: 5 V --- 0.75 A

DISTRIBUTOR

epi24 GmbH, Am Kupfergraben 6A, 10117 Berlin – Germany

epi24 GmbH reserves the right to technical changes and changes to the design that serve to improve the device.

Produced in 2018.

Made in China.





WARNING

For perfect use of the product, please note the following:

- Keep the product away from children, especially small children.
- Always clean the product according to the instructions given here.
- Do not expose the product or the charging device to direct sunlight or UV light for a long period of time.
- Avoid high temperatures.
- Never immerse the cable in water or other fluids, and never rinse it under running water.
- Do not charge the product when one of the components is damaged.

If you wish to use the product under any of the circumstances below, please consult your doctor:

- During pregnancy or shortly after giving birth
- Skin irritations / skin diseases
- Other health problems
- If you have physical allergic reactions to the material

Please also note the following in order to use the product safely:

- Never use the product for longer than 15 minutes on any one area.
- Do not use the product if you have a pacemaker.
- Only use the product for the intended purpose, for clitoral stimulation.
- Stop use immediately if you experience pain or discomfort.

RECHARGEABLE BATTERY

The device has an integrated lithium-ion rechargeable battery. The rechargeable battery may not be burnt, dismantled, or exposed to temperatures above 60°C. If overheated, the rechargeable battery, and therefore also the device, may be damaged. This device is only suitable for users with restricted physical, sensory, or psychological abilities, or without any experience or previous knowledge, when appropriate supervision or detailed instruction on the use of the device is provided by a responsible person. Ensure that children do not play with the device. If you notice an unusual noise, switch off the stimulation device immediately and refrain from further use.

ENVIRONMENTAL PROTECTION

(note on batteries and waste electronic devices)

As a distributor of electronic devices, we are legally obliged to accept the return of waste electrical and electronic devices free of charge. We expressly state that you as the user are legally obliged to return used batteries.

Never throw away electronic devices or batteries in household waste. The symbol shown below, which is also attached to our electronic items, is intended to expressly remind you of this.



For further information, in particular with regard to returning batteries and electronic devices, see the "Terms and Conditions" section of our website.

GEWÄHRLEISTUNG

NORMERFÜLLUNG

Dieses Gerät erfüllt sämtliche Normen bezüglich elektromagnetischer Verträglichkeit (EMV). Das Gerät ist sicher im Gebrauch, sofern es ordnungsgemäß und entsprechend den Anweisungen in dieser Bedienungsanleitung verwendet wird.

GEWÄHRLEISTUNG UND FREIWILLIGE HERSTELLERGARANTIE

epi24 GmbH übernimmt gegenüber Verbrauchern für Womanizer-Produkte, zusätzlich zur gesetzlichen Gewährleistung, die dem Verbraucher gegenüber seinem Verkäufer zusteht, eine freiwillige Herstellergarantie.

Die Bedingungen zur freiwilligen Herstellergarantie findest Du auf unserer Website im Abschnitt „Garantiebedingungen“.

WARRANTY

FULFILLMENT OF STANDARDS

This device fulfills all standards relating to electromagnetic compatibility (EMC). The device is safe to use as long as it is used correctly and in accordance with the instructions given in this user manual.

WARRANTY AND VOLUNTARY MANUFACTURER'S WARRANTY

epi24 GmbH offers customers a voluntary manufacturer's warranty for Womanizer products in addition to the statutory warranty to which consumers are entitled with respect to sellers.

The conditions with respect to the voluntary manufacturer's warranty are on our website, under "Warranty Conditions."

www.womanizer.com